



INTEGRAL® Series (Flow Sensor and PLC)

VERACITY® Series (Flow Sensor and PLC)

CADARO BASE/PRO/Enterprise Software

TECHNICAL OPERATIONS MANUAL

CADARO 600 S Tyler St Suite 2009 Amarillo, TX 79101

"Patent": www.cadaro.com

CADARO®, INTEGRAL®, VERACITY® are registered trademarks of 100th Meridian Ventures, LLC.

Copyright © 2024 M&S Flowmatics, Inc. All Rights Reserved.

Version: 9.4.25
Software: 25.02

CONTENTS

INTEGRAL PRODUCT DESCRIPTION	5
HOW THE INTEGRAL FLOW SENSOR WORKS	5
BEST SUITED APPLICATIONS	5
LIMITATIONS	5
ENVIRONMENTAL RATINGS (CONTROL BOX, JUNCTION BOX, AND LOADCELL)	5
INTEGRAL SERIES FLOW SENSOR ASSEMBLY AND INSTALLATION	6
BEFORE INSTALLATION	6
ASSEMBLY OF FLOW SENSOR	6
SENSOR INSTALLATION	7
POST-INSTALLATION	7
VERACITY PRODUCT DESCRIPTION	8
HOW THE VERACITY FLOW SENSOR WORKS	8
BEST SUITED APPLICATIONS	8
LIMITATIONS	8
ENVIRONMENTAL RATINGS (CONTROL BOX, JUNCTION BOX, AND LOADCELL)	8
VERACITY SERIES FLOW SENSOR ASSEMBLY AND INSTALLATION	9
BEFORE INSTALLATION	9
ADDITIONAL INSTALLATION SITE CONSIDERATIONS	9
ASSEMBLY OF VERACITY FLOW SENSOR	10
INSTALLATION	12
POST-INSTALLATION	12
PLC CONTROL BOX INSTALLATION	13
BOX LOCATION	13
PLC CONTROL BOX POWER REQUIREMENTS	14
PLC MODBUS TCP DESCRIPTION	14
PLC MODBUS TCP PIN ASSIGNMENT	14
PLC IP ADDRESS	14
SIGNAL AMPLIFIER	ERROR! BOOKMARK NOT DEFINED.
START-UP INSTRUCTIONS	16
STARTUP	16
LICENSING	17
INITIALIZATION	18
MAIN MENU	24
FLOW SENSOR	24
CALIBRATION	28
ALARMS	34
DIAGNOSTICS: PASSWORD PROTECTED FOR SUPERVISOR LEVEL ACCESS	41
TARGET/PRESET TECHNICAL DATA SHEET	48
OBJECTIVE	48

SCREEN CONTROL	48
WIRING INSTRUCTIONS.....	51
VOLUME CONTROL TECHNICAL DATA SHEET.....	52
OBJECTIVE.....	52
SCREEN CONTROL	52
WIRING INSTRUCTIONS.....	54
COUNT CONTROL TECHNICAL DATA SHEET	55
OBJECTIVE.....	55
SCREEN CONTROL	55
WIRING INSTRUCTIONS.....	57
AIR CONTROL TECHNICAL DATA SHEET	58
OBJECTIVE.....	58
SCREEN CONTROL	58
WIRING INSTRUCTIONS.....	61
REMOTE RESET (HARDWIRED) TECHNICAL DATA SHEET.....	62
OBJECTIVE.....	62
WIRING INSTRUCTIONS.....	63
MARQUEE TECHNICAL DATA SHEET.....	64
OBJECTIVE.....	64
WIRING INSTRUCTIONS.....	64
HMI COMMS TECHNICAL DATA SHEET	65
OBJECTIVE.....	65
SCREEN CONTROL	65
TESTING	65
USING REMOTE CAPABILITIES.....	66
MODBUS TECHNICAL DATA SHEET	67
OBJECTIVE.....	67
SCREEN CONTROL	67
TESTING	68
DATA READS.....	68
DATA WRITES.....	68
CADARO MODBUS REGISTER MAP.....	69
LOADING SOFTWARE FROM USB FILE	75
TARE AND WEIGHT FACTOR	75
CALIBRATION VALUES	76
TROUBLE-SHOOTING TIPS	77
SLOW OPERATION OR DELAYED SCREEN TRANSITIONS	77
INCORRECT GROSS READING.....	77
UNRECOGNIZED FLOW RATE BY THE PLC.....	77
DATA SHARING ISSUES BETWEEN PLC AND SITE AUTOMATION SYSTEM VIA ETHERNET.....	77
OPERATOR SCREEN ISSUES.....	77
LOSS OF FACTORY SETTINGS DUE TO POWER LOSS	77

NO SIGNAL FROM FLOW SENSOR(S)	78
NAN (NOT A NUMBER) VALUE	78
SERVICE AND REPAIR	78
CONTACT PHONE NUMBER AND EMAIL ADDRESS	78
WARRANTY	78
INTEGRAL SPECIFICATIONS	79
PRODUCT WEIGHTS	79
RATED CAPACITY	79
FLOW SENSOR DIMENSIONS	80
INTEGRAL FLANGES	82
VERACITY SPECIFICATIONS	84
PRODUCT WEIGHTS	84
RATED CAPACITY	84
FLOW SENSOR DIMENSIONS	85
VERACITY FLANGES	87
PLC CONTROL BOX INFORMATION	88
SIGNAL OUTPUT VOLTAGE	88
PLC CONTROL BOX	88
POWER RATING	88
REQUIRED POWER AND SUGGESTED UPS	88
PLC CONTROL BOX DIMENSIONS	88
PLC WIRING DIAGRAM	90
BATTERY REPLACEMENT GUIDE: HMI AND PLC BATTERIES	90
CADARO LIMITED WARRANTY	95
RECOMMENDED INFORMATION TO BE STORED IN PLC CONTROL BOX	96

INTEGRAL PRODUCT DESCRIPTION

HOW THE INTEGRAL FLOW SENSOR WORKS

The patented Integral flow sensor from CADARO is designed to measure the real-time flowrate, batch weight, and total accumulated weight of dry flowable materials. Utilizing advanced load cell signal processing technology, the flow sensor is often installed in-line within an existing non-vertical pipe/chute where the material flows. As the product passes through the sensor, it generates an electrical signal that is transmitted to the CADARO PLC control box. The control box employs proprietary software to convert the signal into easily readable data. The Integral brand is synonymous and replaces the previous NV product series.

For seamless integration, the Integral flow sensor can be connected to an existing automation system using the CADARO Modbus TCP communications. This is a CADARO CONNECT [Enterprise Plan](#) feature. (Contact CADARO Service for directions).

BEST SUITED APPLICATIONS

The Integral Flow Sensor is particularly well-suited for the following applications:

- Dry flowable materials characterized by low moisture content and relatively clean composition.
- Processes involving the gravity-fed flow of material in a non-vertical direction (45-60 degree angle from horizontal) with a consistent flow rate.
- Facilities equipped to perform material calibration tests during initial setup and as required.

LIMITATIONS

While the Integral Flow Sensor offers exceptional performance in numerous scenarios, it may not be suitable for the following applications:

- Situations involving non-uniform material flow or materials with a long drop, leading to excessive material velocity.
- Environments experiencing abrupt changes in temperature or material moisture, which can affect the accuracy of measurements.
- Installation sites subject to excessive motion, vibration, or exposure to electronic and mechanical shocks.
- Outdoor installations or locations with ambient temperatures below 20°F (-6.7°C) or above 120°F (49°C).
- Applications requiring NTEP certification for legal trade purposes.
- Installation sites located within 5 feet of strong RF waves or electromagnetic interference sources.

To ensure optimal performance and accurate measurements, please note these limitations when selecting the installation location and relying on the Integral Flow Sensor.

ENVIRONMENTAL RATINGS (CONTROL BOX, JUNCTION BOX, AND LOADCELL)

The control box enclosure and the loadcell junction box will be treated separately. Both shall meet Class 2 Div 1 hazardous location ratings. The CADARO equipment is not intended to be used in a Class 1 environment.

The control box contains the PLC, HMI, and other related equipment. (Confirm with CADARO when the ratings below are required for site equipment.)

- Control box NEMA Rating: 6P
- Control box IP Rating: IP67

The junction box contains an electrical union of the loadcell cable to the sensor cable. It is located near or on the sensor box.

- Junction box NEMA Rating: 6P
- Junction box IP Rating: IP67

The loadcell for Integral series are IP Rating: IP67
0°F – 150°F

INTEGRAL SERIES FLOW SENSOR ASSEMBLY AND INSTALLATION

BEFORE INSTALLATION

Verify if the material flow rate falls within the rated capacity of the Integral flow sensor. Calculate the flow rate by measuring the time it takes for a known weight of material (pre- or post-weighed) and convert the measurement to pounds per minute (or as specified for your application). Refer to the chart below to determine the appropriate Integral flow sensor.

Figure 1: Integral Sub-Models Specifications

MODEL	Low Operating Range (lbs/min)*	High Operating Range (lbs/min)*	Inlet/Outlet Pipe Size (diameter round/square)*	Configuration	Flow Sensor Dimensions (L x W x H)	Flow Sensor Weight (lbs)
INTEGRAL NR/2K INTEGRAL NRL/2K	800	2,000	6" OD	Round	32 1/8" x 13" x 11 3/4"	67 -
INTEGRAL NS/5K INTEGRAL NSL/5K	1,750	5,000	9 3/4" x 9 3/4" ID	Square	30 3/8" x 16 1/4" x 15"	135 200
INTEGRAL NS/20K INTEGRAL NSL/20K	5,000	20,000	17 3/4" x 17 3/4" ID	Square	36 1/2" x 23 3/4" x 24 3/4"	210 275
INTEGRAL NS/50K INTEGRAL NSL/50K	17,500	50,000	29 3/4" x 29 3/4" ID	Square	36 1/2" x 37" x 35 3/4"	375 425

*Operating range can be calibrated to measure lower flow rates but overall range and accuracy requirements need to be considered.

Before installation, ensure that the system is in working condition. This check ensures that the sensor has not been damaged during shipment. To perform this check, follow these steps:

ASSEMBLY OF FLOW SENSOR

Note: Your system will include a shipping bolt and a safety bolt. Remove the shipping bolt. For the Integral flow sensor, you may be able to access these bolts from the outlet without removing the side piece. If the side panel is removed, the shipping bolt spacer can be seen above the internal sensing box.

Steps to Remove Shipping Spacer

1. Remove the shipping spacer by loosening the shipping bolt running from the external top of the sensor through the sensing box.
2. Note: If the shipping bolt is tightly secured, apply pressure to the bottom of the inner square sensing box to remove it.
3. Take a smaller length bolt with nut [1/4" x 3/4" standard bolt and 1/4" nut not provided – purchase separately] and insert it into the sensor housing in place of the shipping bolt, making sure it does not extend into the inside of the sensing box, but instead remains flush with the interior surface of the sensing box/housing. Tighten the nut to secure both the bolt and the nut in place.

Steps to Lower the Bottom Shipping Bolts

1. Loosen the nuts on the shipping bolts located on the bottom side of the sensor housing.
2. Loosen the bolts until they are flush with the inside bottom surface of the sensor. There are two bolts, one under each load cell, for the inclined sensor.
3. Leave the bolts flush with the inside bottom surface of the sensor and tighten the nuts.

Once the shipping spacer is removed and the shipping bolts are lowered, place the system on a level/horizontal surface

and connect the PLC control box to the sensor using the provided cable.

1. Connect the male end of the load cell cable to the Integral flow sensor junction box and the female end to the to the PLC control box.
2. If the loadcell is reading correctly, there will not be an alarm described as 'Signal Fault' or 'Signal Max'. Apply slight pressure to the interior sensor box and watch for weight to begin accumulating, indicating successful communication with the load cells.
3. If the weight factor is zero or if the load cell weight is signal fault or signal max then refer to the Alarm section below.

System Confirmation with Weight

1. Place a small weight, such as a standard 500 or 1,000 gram weight, onto the sensing plate. If a standard weight is not available, an unopened bottle of water can be used as a substitute.
2. Once placed inside the sensing box, the gross weight should increase steadily, and the net weight should be greater than zero. If this does not occur, please contact CADARO as it is possible that your sensor has been damaged during shipment.
3. **Note:** Resecure the sensing box using the shipping bolts and shipping spacers to protect your system during installation. Ideally, the removal of the shipping spacer and lowering of the shipping bolts within the sensor should be done after installation. However, if it is difficult to access all areas post-installation, these steps can be performed before installation; however, the unsecured unit must be handled with care.

SENSOR INSTALLATION

Best Practices/Guidelines

1. A manual gate or choke immediately upstream or downstream of automatic gate will ensure consistent and repeatable flow.
2. Certain system configurations may require the inclusion of gate/choke immediately upstream of the flow sensor.
3. The direction of gate travel should be oriented to direct the incoming material pathway along the bottom portion of the flow sensor. Avoid orientations that direct material towards the top side of the flow sensor.
4. For installations without a gate or choke, avoid placement of the sensor near inflection points that change either the direction or speed of material flow.

Angle of Installation

The Integral Flow Sensor should be installed at an angle where the dry flowable material being measured flows through a chute and contacts the internal sensing plate. The material should not be free-falling, but instead material should flow in a uniform, consistent manner making even contact with the internal bottom and side surfaces of the sensor. Install the sensor at an angle which ensures proper flow, generally between 45 and 60 degrees from horizontal.

Installation Considerations

The sensor will come with an inlet and outlet pipe or bolt holes on the inlet/outlet flange for installation. Do not use the main body between the inlet/housing or outlet/housing to secure the sensor. Ensure that the sensor is leveled perpendicular to the direction of flow. Material should flow over the internal sensing plate in an even and consistent (imagine water or thick oil/cheese-like) manner. Use a level to verify that the sensor is level in the plane perpendicular to the direction of product flow. An angled installation can negatively affect accuracy.

Important: Avoid operating welding equipment in the vicinity of the Integral flow sensor when it is installed. Prior to any welding activities near or on the equipment where the Integral flow sensor is installed, remove the Integral flow sensor. Any damage caused to the Integral flow sensor by welding equipment will not be covered under the warranty. Refer to Section 10 for further details.

POST-INSTALLATION

After a 30-minute waiting period, enter your customer specific license provided by CADARO.

VERACITY PRODUCT DESCRIPTION

HOW THE VERACITY FLOW SENSOR WORKS

The patented Veracity flow sensor from CADARO is designed to measure the real-time flowrate, batch weight, and total accumulated weight of dry flowable materials. Utilizing advanced load cell signal processing technology, the flow sensor is often installed in-line within an existing vertical pipe/chute where the material flows. As the product passes through the sensor, it generates an electrical signal that is transmitted to the CADARO PLC control box. The control box employs proprietary software to convert the signal into easily readable data. The Veracity brand is synonymous and replaces the previous FM product series.

For seamless integration, the flow sensor can be connected to an existing automation system using the CADARO Modbus TCP communications. This is a CADARO CONNECT [Enterprise Plan](#) feature. (Contact CADARO for more information at info@cadaro.com.)

BEST SUITED APPLICATIONS

The Veracity Flow Sensor is particularly well-suited for the following applications:

- Dry flowable materials characterized by low moisture content and relatively clean composition.
- Processes involving the gravity-fed flow of material in a vertical direction (90-degree angle from horizontal) with a consistent flow rate.
- Facilities equipped to perform material calibration tests during initial setup and as required.

LIMITATIONS

While the Veracity Flow Sensor offers exceptional performance in numerous scenarios, it may not be suitable for the following applications:

- Situations involving non-uniform material flow or materials with a long drop, leading to excessive material velocity.
- Environments experiencing abrupt changes in temperature or material moisture, which can affect the accuracy of measurements.
- Installation sites subject to excessive motion, vibration, or exposure to electronic and mechanical shocks.
- Outdoor installations or locations with ambient temperatures below 20°F (-6.7°C) or above 120°F (49°C).
- Applications requiring NTEP certification for legal trade purposes.
- Installation sites located within 5 feet of strong RF or electromagnetic interference sources.

To ensure optimal performance and accurate measurements, please note these limitations when selecting the installation location and relying on the Veracity Flow Sensor.

ENVIRONMENTAL RATINGS (CONTROL BOX, JUNCTION BOX, AND LOADCELL)

The control box enclosure and the loadcell junction box will be treated separately. Both meet Class 2 Div 1 hazardous location ratings. The CADARO equipment is not intended to be used in a Class 1 environment.

The control box contains the PLC, HMI, and other related equipment. *(Confirm with CADARO when below ratings required for site equipment.)*

- Control box NEMA Rating: 6P
- Control box IP Rating: IP67

The junction box contains an electrical union of the loadcell cable to the sensor cable. It is located near or on the sensor box.

- Junction box NEMA Rating: 6P
- Junction box IP Rating: IP67

The Transducer Techniques loadcell for Veracity series is not officially rated. The manufacturer lists the electrode coating

as moisture proof.

Temperature Range: -14°F – 140°F

VERACITY SERIES FLOW SENSOR ASSEMBLY AND INSTALLATION

BEFORE INSTALLATION

1. Determine the inlet pipe diameter by direct measurement if possible or measure the pipe circumference and divide by 3.14 to calculate the diameter. For other diameters other than the primary sizes, an adapter will be required.
2. Determine if the correct length of vertical spouting can be removed for the Veracity flow sensor installation. If the sensor length exceeds the amount of vertical spouting available, then either the pipe configuration, type of sensor, or space itself may need to be changed.
3. Determine if the flow rate of the material is within the rated capacity of the Veracity flow sensor. Calculate the flow rate by timing a known weight of material (either pre-weighed or post-weighed) and converting the numbers to pounds per minute (or the flow rate specified for your application). Refer to the chart below to determine the appropriate Veracity flow sensor.

Figure 2: Veracity Sub-Models Specifications

MODEL	Low Operating Range (lbs/min)*	High Operating Range (lbs/min)*	Inlet/Outlet Pipe Size (diameter round/square)*	Configuration	Flow Sensor Dimensions (L x W)	Flow Sensor Weight (lbs)*
VERACITY VR/600	200	600	4" & 6" ID	Round	18 ½" x 11" (4") 22" x 11" (6")	25 (4") 28 (6")
VERACITY VR/2K	800	2,000	6" ID	Round	22 ¼" x 15"	50
VERACITY VR/4K	1,600	4,000	8" & 10" ID	Round	23" x 17" (8") 26" x 17" (10")	60 (8") 65 (10")
VERACITY VR/5K	2,000	5,000	10" ID	Round	26" x 21"	75

**Operating range can be calibrated to measure lower flow rates but overall range and accuracy requirements need to be considered.*

ADDITIONAL INSTALLATION SITE CONSIDERATIONS

- **Vertical Orientation:** Ensure that the Veracity flow sensor is installed in a vertical position to ensure proper functionality and accurate measurements.
- **Handle with Care:** The load cells in the Veracity flow sensor are sensitive to mechanical shock, vibration, and drops. Avoid dropping the sensor or subjecting it to excessive vibration or mechanical shock. Additionally, do not perform any welding activities on or near the sensor. If welding is necessary nearby, it is recommended to remove the Veracity flow sensor until the welding process is completed to protect the load cells from potential damage.
- **Uninterrupted Material Flow:** The material being measured must flow freely through the Veracity flow sensor. To ensure smooth flow, prevent material backup from occurring either from above or below the sensor. If necessary, consider installing a flow regulator or surge bin above the Veracity flow sensor to maintain proper material flow.
- **Steady Material Flow:** For optimal performance, the Veracity flow sensor operates best with a steady material flow. Avoid surging or fluctuating flows as they may affect the accuracy of the measurements.

ASSEMBLY OF VERACITY FLOW SENSOR

Before starting the assembly, carefully unpack all the components and compare them to the delivery notice to ensure that all necessary parts are available.

Materials Required for Assembly:

Veracity VR/600-VR/4K

- Wrench set (SAE) for flange clamp bolts
- Phillips screwdriver
- Blue Locktite (Anti-seize compound)


Veracity VR/5K

- Size 13 socket wrench or ½" socket wrench
- Wrench
- Phillips screwdriver
- Blue Locktite (Anti-seize compound)

Note: Always prioritize safety while handling, assembling, and installing the Veracity flow sensor.

1. Organizing Components:


Arrange the components required for the Veracity flow sensor assembly, including:



2. Attaching the Flow Sensor Dome:

Position the dome above the dome base plate to align the screw with the connector on the base plate. Before tightening, apply a small amount of Loctite to the screw. Use a Phillips screwdriver to secure the dome with the bolt. While securing the bolt, hold onto the dome with one hand. Please hand-tighten the bolt and avoid using power tools to prevent damage to the load cell. Be cautious not to apply excessive downward pressure on the cap screw, as it may damage the load cell.

Important: Whether it is a new installation or cap replacement, always insert the load sensor shipping bolt prior to performing the task.



3. Removing the Load Sensor Shipping Bolt:

Rotate the sensor main housing to gain access to the load sensor shipping bolt. Once located, carefully remove the shipping bolt. After removing the shipping bolt, return the housing to the upright position.

Important Note: The shipping bolt is intended to provide support during shipping and cap installation. Take extra care when handling the Veracity flow sensor after removing the shipping bolt.


4. Placing the Outlet Transition:

Position the outlet transition on a stable work platform or surface.



5. Attaching the Main Housing:

Place the Veracity flow sensor main housing on top of the outlet transition. Ensure stability of the components while attaching the flange clamp. Before attaching the lower flange clamp, ensure that it securely encloses the entire transition and housing rings. Close the latch mechanism to secure the retaining clamp, then insert the securing pin as indicated in the provided photo.



6. Placing the Inlet Transition:

Position the inlet transition on top of the main flow sensor housing. Ensure stability of the components while attaching the flange clamp.

Final Installation:

Complete the installation in a vertical application, attaching the Veracity flow sensor to the site piping using appropriately sized flanges and flange clamps determined during the pre-site assessment.

Once the assembly and installation are complete, you can proceed to attach the control box cable to the flow sensor and PLC control box, followed by the calibration process.

Once the shipping spacer is removed and the shipping bolts are lowered, place the system on a level/horizontal surface and connect the PLC control box to the sensor using the provided cable.

1. Connect the male end of the load cell cable to the Veracity flow sensor junction box and the female end to the to the PLC control box.
2. If the loadcell is reading correctly, there will not be an alarm described as 'Signal Fault' or 'Signal Max'. Apply slight pressure to the interior sensor box and watch for weight to begin accumulating, indicating successful communication with the load cells.
3. If the weight factor is zero or if the load cell weight is signal fault or signal max, then refer to section 5.3 Alarm

System Confirmation with Weight

1. Place a small weight, such as a standard 500 or 1,000 gram weight, onto the sensing plate. If a standard weight is not available, an unopened bottle of water can be used as a substitute.
2. Once placed inside the sensing box, the gross weight should increase steadily, and the net weight should be greater than zero. If this does not occur, please contact CADARO as it is possible that your sensor has been damaged during shipment.

Note: Resecure the sensing box using the shipping bolts and shipping spacers to protect your system during installation. Ideally, the removal of the shipping spacer and lowering of the shipping bolts within the sensor should be done after installation. However, if it is difficult to access all areas post-installation, these steps can be performed before installation; however, the unsecured unit must be handled with care.

INSTALLATION

Best Practices/Guidelines

- A manual gate or choke immediately upstream or downstream of automatic gate will ensure consistent and repeatable flow.
- Certain system configurations may require the inclusion of gate/choke immediately upstream of the flow sensor.
- For installations without a gate or choke, avoid placement of the sensor near inflection points that change either the direction or speed of material flow.

The Veracity flow sensor is installed by removing a section of vertical spouting and replacing it with the Veracity flow sensor, as specified in the table below. Metal angle flanges will be used on the existing metal piping to match the flanges on the Veracity flow sensor, facilitating the installation process.

Note: Stainless steel bolts are commonly used to secure the V-band flanges to both the Veracity flow sensor and the existing piping. Regular steel bolts and nuts can also be used. If stainless steel bolts and nuts are utilized, it is recommended to apply an anti-seize compound to prevent cold fusion or galling of the bolts.

Important: Avoid operating welding equipment in the vicinity of the Veracity flow sensor when it is installed. Prior to any welding activities near or on the equipment where the Veracity flow sensor is installed, remove the Veracity flow sensor. Any damage caused to the Veracity flow sensor by welding equipment will not be covered under the warranty. Refer to Section 10 for further details.

POST-INSTALLATION

After a 30-minute waiting period, enter your customer-specific license provided by CADARO.

PLC CONTROL BOX INSTALLATION


BOX LOCATION

Choose a safe, dry, and convenient location to mount the PLC control box.

We recommend the total cable length between the control box and sensor box be no more than 300 feet. Connect the RJ45 end at the Veracity flow sensor box to the RJ45 end at the PLC control box.

Depending on the customer, a prefabricated signal cable or a bulk cable without ends may be included. In either case, this cable may be altered to the customer's liking. Qualified personnel should follow the pinout diagram below to ensure the wiring is done correctly. Necessary tools are required.


Figure 3: RJ45 Pinout Diagram



Important: Avoid placing the PLC control box in direct sunlight. Treat the PLC control box with the same care as a computer and avoid placing it where it will be exposed to less-than-ideal conditions. CADARO recommends placing the control box inside a building or, if that is not possible, in its own enclosure to provide shelter and protection from external conditions.

PLC CONTROL BOX POWER REQUIREMENTS

Figure 4: PLC Power Wiring Diagram



The PLC control box is designed to be plugged into a standard 120V AC outlet. (Reference the chapter and section titled Specifications, Required Power and Suggested UPS.)

Should the customer decide to provide power without using the provided 3-prong outlet, reference the yellow highlighted wiring code in the above picture.

PLC MODBUS TCP DESCRIPTION

For installations with an existing automation system, the flow sensor signal can be managed and delivered via Modbus TCP to an existing automation platform. Our PLC acts as the slave device storing data inputs and outputs to registers accordingly.

More about the Modbus is found in the Initialization section below. This is a CADARO CONNECT Enterprise Plan feature.


PLC MODBUS TCP PIN ASSIGNMENT

The connector used is a standard RJ45 Ethernet connector. The connector pinout is the same as described above in the figure labeled 'RJ45 Pinout Diagram'.

PLC IP ADDRESS

1. Download the IP configuration program (AVG IPConfig 1.0.2 for Windows) onto your PC.
 - a. Provided by Cadaro.
2. Connect one ethernet cable from your PLC control box RJ45 Port to your PC.
3. Open the PLC control box and confirm that there is an ethernet cable connection between the PLC, and the RJ45 plug on the top of the PLC control box.
4. If there is no ethernet cable between the RJ45 and the PLC, plug directly into the ethernet jack on the PLC.
5. Make sure all devices are powered on.
6. Install and open the 'AVG IPConfig' program on your PC and click on "Scan Devices."

Figure 5: AVG IP Config Dialog Box



7. If you only have a connection between the PLC control box and PC, it should detect only one device.
8. If you have multiple networks, choose the device you want to edit from the list.
9. If necessary, change the IP address, Subnet mask, and gateway to your choice. Press “Set Ethernet Parameters” and wait for the system to update.
10. Power cycle (restart) the control system and "Scan Devices" to ensure the IP settings are as desired. It is necessary to restart the PLC control box to engage the new IP Address. Restart PLC by turning off the power breaker for 30 seconds and turning it back on.

Figure 6: AVG IP Config IP Parameters (Example)




Table 1: Typical IP Parameters

IP Address	192	168	1	X
Subnet Mask	255	255	255	0
Gateway	Empty			

11. Typical private network ethernet parameters example. Consult IT or CADARO for further support if needed.


It is recommended to store the IP address within the PLC control box for future reference either on a flash drive that is kept **INSIDE** the PLC control box (but not plugged into anything) or written down on a piece of paper or notepad and stored **INSIDE** the PLC control box for easy reference.

START-UP INSTRUCTIONS

STARTUP


Pre-Licensed Screen

Figure 7: Unlicensed Loadout/Startup Screen



Licensed Screen

Figure 8: Licensed Loadout/Startup Screen



'Loadout Summary' screen can be treated as a default/main screen. After license is entered, this screen gives most of the pertinent information needed to run.

This screen can be later accessed from the 'Flow Sensor Menu' screen.

LICENSING

Pre-Licensed Screen

Figure 9: Unlicensed Screen



From bootup, if license has not been configured, the above screen will appear.

Figure 10: License Accepted Screen.



Enter the prescribed license, if correct, the software will allow for advancement to the below screen.

Post-Licensed Startup Screen

Figure 11: Licensed Bootup or Post-License Entry Screen




From bootup, if license has been previously accepted, the above screen will appear. This screen will also appear after the correct license has been entered.

INITIALIZATION

Pre-Initialized

Figure 12: Before Any Initialization



As seen before anything has been initialized to a specific customer or flow sensor box. Please verify the 'Software Version' matches what CADARO has prescribed. If not, contact CADARO.

'Setup Comms/IO' is only accessible by having a CADARO CONNECT Pro or Enterprise Plan. The functionalities within this option are described in further detail below.

Model Selection

Figure 13: Model Selection Screen

SENSOR CHANNEL ENABLE							
CHANNEL 1		CHANNEL 2		CHANNEL 3		CHANNEL 4	
ENABLED		ENABLED		ENABLED		ENABLED	
MODEL SELECTION							
				MODEL TYPE			
CH 1 ON	CH 2 OFF	CH 3 OFF	CH 4 OFF	VERACITY SELECTED		SELECT INTEGRAL	
MODEL RANGE - VERACITY							
600		2000		4000		5000	
SAVE CHANNEL 1						BACK	

Take care when selecting the model type and range. The model selection step can only be performed once, thereafter, the license will need to be reinitialized.

Up to four channels/sensors can be enabled per control box.

- Assign each channel the proper model and range
- Save channel model and range before switching to next channel

Time

Figure 14: System Time Setup Screen

SETUP TIME						
YEAR		MONTH		DAY		
25		9		4		
HOUR		MINUTE		SECOND		
9		53		10		
REDO TIME						BACK

HOLD

TO UPDATE TIME:
PRESS HOLD FOR > 6 SEC
FOLLOW "CLOCK"

The system time is important for datalogging time stamps.
To manually update time, gently press and hold the top left 'HOLD' button for over 6 seconds.

Setup Communications and IO

Figure 15: Comms, Modbus, and IO Setup Screen



'Setup HMI Comms' and 'Modbus Enable' require a CADARO CONNECT Enterprise Plan. HMI Comms will allow for remote access to the HMI screen and/or the stored data from a desktop.

Modbus turns on the data within the software to allow for remote monitoring and/or control.

If Enterprise Plan subscriber: See "CADARO ENTERPRISE Software Technical Operations Manual" for further instruction.

- "HMI Comms Technical Data Sheet"
- "Modbus Technical Data Sheet"

'Initialize IO' is only accessible for CADARO Pro Plan subscribers. See "PRO Software Technical Operations Manual".

Figure 16: Amplifier and Analog Inputs




Figure 17: Discrete Input Setup Screen






Figure 18: Discrete Output Setup Screen



Tune/Tare Sensor and Set Units

Figure 19: Tune, Tare, and Units Screen



The ‘tune amplifier/tare sensor’ screen is used to visualize the reading from the amplifier for tuning purposes and tare the net reading if needed. Tuning is typically only needed once by CADARO. If CADARO Support prescribes tuning, the instructions will be delivered at that time.

Taring is meant to be an automatic functionality. If you find the tare does not match the raw (amplifier reading), a manual tare shall be done.


The ‘Unit Selection’ section allows for setting prescribed or customized units.

- Default is lb/min
- Prescribed kg/time
- Custom Example: Short ton = 2000 lb => 1lb/2000lb=0.0005
 - This 0.0005 value is place in the ‘Unit/Lb’ entry box
- Volume Example: 56 lb/bushel
 - This 56 value is place in the ‘Lb/Unit’ entry box
- Density Example: 200 seeds/lb
 - This 200 value is place in the ‘Unit/Lb’ entry box

All subsequent screens and value displays will represent the selected unit/time value.


Post-Initialization

Figure 20: After All Initialization Is Complete



If for any reason the 'Model Selection' needs to be redone, the confirmation screen below will appear.


Figure 21: Void License Confirmation



If 'Continue' is clicked, the license will void and a new license will be required to proceed.


MAIN MENU

Figure 22: Main Menu Screen. For Post-Initialization Tasks



FLOW SENSOR

Figure 23: Flow Sensor Menu Screen



Double-Check the 'Active Model Type' and 'Active Model Range' match the installed sensor characteristics for each available channel.

Flow View

Figure 24: Flow View Screen. No Controls Enabled





Figure 25: Flow View Screen. All Controls Enabled




Flow Sensor View screen can be the default screen for operator use once device has been fully initialized and calibrated. Feel free to reach out to CADARO if there are any requests for alterations to this screen.

The target weight capability requires CADARO CONNECT Pro Plan. See “CADARO PRO Software Technical Operations Manual”. More information on ‘Target Presets’ is below.

The air blower capability requires CADARO CONNECT Pro Plan. More information on ‘Air Control’ is below.

Flow Graph

Figure 26: Flow Graph Screen



The Flow Graph screen allows for a trendline and historical visual representation of the 'Current Flow', 'Average Batch Flow', and 'Average Total Flow'. If you request a different value to be trended, contact CADARO.

The y-axis (lbs.) is preset adjustable on the top option bar.

Flow Settings

Figure 27: Flow Settings Screen

FLOW SENSOR CONTROLS		
TARGET SETTINGS	VOLUME SETTINGS	
COUNT SETTINGS	AIR SETTINGS	
ENTER SCALE INFO: FOR RECORD		
SCALE WEIGHT	SCALE BATCH #	SAVE SCALE
0.0	0	
BACK		

'Target Presets' and 'Air Control' are covered in further detail below.

The 'Enter Scale Info: For Record' section allows for manual entry of the scale weight and respective batch for the scale weight. This data saves to the microSD card upon clicking 'Save Scale'. This data can later be used as reference.

Flow Settings: Target Presets

Figure 28: Target Presets Screen





Figure 29: Target Control Screen



The target preset functionality is intended to be used as a controllable output of the PLC when the target is met.

Custom or Preset controls can be controlled from this ‘Target Control’ screen.

If required, a batch can be started/stopped from this screen to open/close a gate.

- The tare/empty weight represents the empty truck weight or starting point of a batch total weight.
- The target/full weight represents the desired amount for the batch.

Example: If the target is 80,000 lbs., PLC will shut slide gate at 79,000 lbs. to meet the target. This is tunable.

The target weight capability requires CADARO CONNECT Pro Plan. If Pro Plan subscriber: See “CADARO PRO Software Technical Operations Manual”, “Target Preset Technical Data Sheet” for further instruction.

Flow Settings: Air Control

Figure 30: Air Control Screen



The auto/manual air blower control is intended to clean the Integral flow sensor after each batch or other criteria.


Example: Heavy buildup of dust or residue from material may cause inaccurate readings.

The air blower capability requires CADARO CONNECT Pro Plan. If Pro Plan subscriber: See “CADARO PRO Software Technical Operations Manual”, “Air Control Technical Data Sheet” for further instruction.

CALIBRATION

Calibration Menu

Figure 31: Calibration Menu Screen




All calibration functions derive from this ‘Calibration Menu’

The 'Profile Load' display will indicate which profile was last loaded, if applicable.

Perform Calibration Menu

Figure 32: Perform Calibration Menu Screen




Note: 'Perform Cal 2' option only appears after Cal 1 has been performed.

'Stop Batch' is used only for calibration scenarios when the process of material is not capable of smooth/quick starts and stops. It can also be used for scenarios when the flow rate of a process takes time to build up to or slowdown from. Pressing 'Stop Batch' will force the software to stop calculating flow, even if material is still flowing.

The physical batch of material used to calibrate a run will need to closely match the calculated batch. Meaning, a manual bypass gate or needs to be swung at the same time 'Stop Batch' is pressed.

Perform Cal 1

Figure 33: Perform Calibration 1 Screen



Calibration screen for Cal 1 depicts three rows of information.

- **Row 1** at the top are all pre-calibration values. These values are used as a baseline to calculate 'real' values in row

3.
 - **Row 2** is for operator control/input.
 1. Ensure the batch has been reset before running a calibration batch.
 2. Input scale weight after material has stopped flowing. This scale weight shall be for the respective calibration batch run.
 3. Press 'Perform Cal 1' after scale weight has been submitted.
 - **Row 3** is real values calculated from pre-calibration and scale weight values.

Perform Cal 2

Figure 34: Perform Calibration 2 Screen

PERFORM CAL 2		CH 1 SELECTED
PRE-CALIBRATION VALUES		
PLC WEIGHT	PRE-FLOW/MIN	BATCH TIME
0.0	0.0	0.0
OPERATOR CONTROL/INPUTS		NO CAL PERFORMED
RESET BATCH	SCALE WEIGHT	PERFORM CAL 2
	0.0	
POST-CALIBRATION VALUES		
ACTUAL FLOW/MIN	CAL FACTOR 2	BACK
0	0.0000	

When a second calibration point is performed and calculated by the software, it is called 'Two-Point Cal'.


Calibration 2 screen is similar to Calibration 1 screen.

- 'Two-Point Cal' uses Cal 1 factors and Cal 2 factors to create a linear slope of calibration information.
- This calibration information is used to apply the appropriate Cal factor to the respective real flowrate along the slope of calibration.

Note: The difference in flowrate between Cal 1 and Cal 2 shall be greater than the 'Cal % Difference' setting. This setting is addressed below in the 'Cal Settings' section.

Manual Cal Factors

Figure 35: Manual Cal Factor Control Screen




From this screen, calibration values can either be forced or manually changed. This screen also acts as a helpful calibration summary screen.

- Forcing will overwrite all predetermined Cal values. This applies to two-point Cal as well.
- Forcing Cal values for C1 or C2 is done by pressing 'Force Cal 1' or 'Force Cal 2'.
- Only a single force can be active at any given time.
- The C values can be manually changed by clicking C1 or C2 and editing the value.

Save Cal Factors

Figure 36: Save Cal Factors Screen



After a calibration has been performed, the active calibration values will be auto populated onto the 'Save Cal Factors' screen.

- This is where a product or flowrate profile can be saved to the software. Select a 'File Element' to save to before clicking 'Save Cal Factors'. If saving to a previously occupied 'File Element' all previously saved information in that particular 'File Element' will be overwritten.

- The 'Product Type' section allows for shorthand notes about the profile. Limited to 10 characters. Examples may include 'Soybean', 'CornFlow2K', 'Milo2Point', '9Aug2023', etc.
- The software will store up to twelve profiles for future loading to the active calibration when needed. The active profile is always the one loaded into the values on this screen.

For manual saving of calibration information, refer to the below table for guidance.


Table 2: Calibration Profile Saving Example

	File 1	File 2	File 3	File 4	File 5	File 6	File 7	File 8	File 9	File 10	File 11	File 12
CAL1												
CAL2												
Pre-Cal Flow1												
Pre-Cal Flow2												
Time1												
Time2												
Scale1												
Scale2												
Tare												
Product												

You may also email the calibration information to CADARO directly at info@cadaro.com

Load Cal Factors

Figure 37: Load Cal Factors Screens



This is the repository of the saved calibration profiles. Four files are depicted on three separate screens to total the twelve files available.

- Select any of the four files by clicking on the top row of buttons.
- Select 'Load' when ready. On the 'Save Cal Factors' screen, the loaded profile is now the active profile.
- 'Clear Profile' will delete the selected profile.

- Be careful to choose the correct profile corresponding to the correct channel.

Delayed/Manual Calibration

Figure 38: Delayed/Manual Calibration

DELAYED/MANUAL CALIBRATION			
SAVE BATCH INFOR FOR DELAYED CALIBRATION			
CHANNEL	BATCH TOTAL	BATCH #	SAVE
0	-1.0e+10	0	
ENTER SCALE AND SELECT CAL FACTOR TO BE ADJUSTED			
SCALE NET WEIGHT	CAL 1	BATCH #	PERFORM
0.0		0	
PERFORM MANUAL ADJUSTMENT			
ADJUST %	CADARO UNDER	CAL 1	ADJUST
0.000			
POSITIVE VALUE ONLY			BACK

Delayed calibration allows for performing a calibration eligible batch, saving it until scale feedback is received, and finally entering the scale weight at a later time.


- Ensure the correct channel is selected
- Perform a clean batch
- ‘Save’ the batch for later
- Enter scale weight for the saved batch
- Ensure the proper cal factor is selected
 - Cal 1 is typically normal/high flow
 - Cal 2 is typically low/reference flow for two point cal
- ‘Perform’ the delayed calibration

Manual calibration adjust allows for minor tweaks to the calibration factor without having to perform a calibration run.

- Ensure the correct channel is selected
- Determine if Cadaro’s calculated results for a batch are over or under the scale feedback
- Enter an averaged % over or under, this value must be positive
- Apply this correction to the correct cal factor
- ‘Adjust’ the cal factor

Cal Settings: Password Protected for Supervisor Level Access

Figure 39: Calibration Settings Screen



The 'Cal % Difference' is an allowable range between Flowrates for Cal 1 and Cal 2.

- For instance, Cal 1 Flowrate of 100 and Cal 2 Flowrate of 79 is acceptable. The % difference is 21%.
- This setting is meant to inform the user of calibration flowrate values being too close, which can cause two-point calibration calculation problems.
- If this condition is violated, it will produce an alarm and nothing more. Specifically, it will continue the calibration calculations as normal, even if they are malfunctioning.

ALARMS

There are seven alarms pre-programmed into the software:

Table 3: Alarm List

Alarm Name	Severity	Solution – Contact CADARO If Needed
Panel/HMI Battery Low	Low	Follow procedure to replace battery with exact match battery
PLC Battery Low	Low	Follow procedure to replace battery with exact match battery
Signal Fault	High	Signal reading 0. Bad loadcell or faulty wiring.
Signal Max Reading	Medium	Signal reading max. Bad loadcell or too much flow.
Auto-Tare Fault	Medium	Tare value not updating. Signal issue or not in auto.
Cal Flowrates Too Close	Low	Cal settings need adjustment. Cal 2 flowrate needs to change.
Uncomputable Cal Factor	High	Cal settings and/or results are not satisfactory for computation.

Alarm List


Figure 40: Alarm Summary Screen



All active alarms will be shown here. Refer to the alarm list above for more information.

Alarm History


Figure 41: Alarm History Screen



All alarms whether active or not will show here. The alarms can be cleared if necessary by clicking 'Clear All'.

Utilities Menu


Figure 42: Utilities Menu Screen



- Re-Initialize will navigate the user to the 'Initialization' screen.

Auto-Tare Graph

Figure 43: Auto-Tare Graph Screen




The 'Auto-Tare Graph' screen is used to visualize the 'noise' of the signal.

- This is a direct comparison of the gross (raw) value from the sensor to the tare (zero) value of the software.
- The 'noise' could be from a handful of interactions to the PLC or Loadcell. For example: radio interference, vibration, temperature, etc.
- If auto-tare is enabled, the drift will re-tare when the drift is beyond the tare dead zone for more than five seconds.

Utility Settings

Figure 44: Utilities Setting Screen



Flow Deadzone: The values used to determine active flow. For example: If the tare is 100 and flow dead zone is 20, then gross will need to be greater than 120 for flow to be considered active.

Possible reasons to change *Flow Deadzone*:

- Considerable noise causing the signal to bounce above the dead zone without actual flow of material. This problem should be fixed in a different way for a long-term solution.
- Material is light weight or slow flow where the signal is not moving enough to be considered active.

Marquee Enable: An optional installation of a remote LED data display device, or Marquee, can be activated. The *Marquee* capability requires a CADARO CONNECT Enterprise Plan.

- If Enterprise Plan subscriber: See document named “CADARO Marquee Tech Sheet”.

Remote Reset Enable: A hardwired push button can be installed to allow for remote resetting of the batch. If other criteria are requested for use by a hardwired push button, please reach out to CADARO Support. The *Remote Reset Enable* capability requires CADARO CONNECT Pro Plan.

- If Pro Plan subscriber: See document named “CADARO Remote Reset (Hardwired) Tech Sheet”.

Weight Factors: Separate screen with multiple options described below.

Auto Tare: Separate screen with multiple options described below.

Load Cell Cal High Value: This value represents the value of the weight used for load cell calibration. After calibration, it should be left as is.

Utility Settings: Weight Factors

Figure 45: Weight Factors Screen

The screenshot shows a screen titled "UTILITY SETTINGS: WEIGHT FACTORS". At the top, it says "CH 1 SELECTED". Below that is a field for "CHANNEL 1 WT FACTOR" with the value "0.500". There is a button labeled "CALCULATE WT. FACTOR" and a "BACK" button in the bottom right corner.

Each sensor has an assigned flow rate capacity as well as a weight factor. This weight factor is what the software uses to calculate the pre-calibration values. These factors should only be adjusted after discussion with CADARO Support.

Utility Settings: Calculate Weight Factor


Figure 46: Calculate Weight Factor Screen

The screenshot shows a screen titled "UTILITY SETTINGS: CALCULATE WEIGHT FACTOR". It has several input fields: "ENTER AVERAGE GROSS" (0), "ENTER AVERAGE TARE" (0), "ENTER EXPECTED FLOW/MIN" (0), and "CH 1 SELECTED". Below these are "CURRENT WT. FACTOR" and "NEW WT. FACTOR", both showing "-1.000e+10". At the bottom are three buttons: "COMPUTE NEW WT. FACTOR", "SAVE WT. FACTOR", and "BACK".

The calculate weight factor screen should be used reserved for Cadaro personnel or operated only with Cadaro support guidance. Changing these values can greatly affect the sensor's calibration.

Utility Settings: Tare

Figure 47: Tare Screen



This is 'Tare Tune' functionality, and it is default enabled. When enabled, the tare will adjust itself to follow any deviations in gross (raw) over time.

The *Tare Tune Deadzone* is the value used to determine if gross has drifted too far from tare, i.e. if gross-minus-tare is greater than 'Tare Tune Deadzone' for greater than five seconds, the tare will 'Auto-Tare'.

The 'Auto-Retare' functionality is default enabled. When enabled, the software will perform a tare each time the batch is reset. This is regardless of drift status.

Passwords

Figure 48: Passwords Screen



The 'Supervisor' password is adjustable by the supervisor only. The default is password '3456'. If changed, do not forget it. This is the only password customers can use to access certain areas of the product functionality.

Data Logging

Figure 49: Data Logging Screen



There are a handful of pre-programmed scenarios in which data is logged to the on-board microSD card. The PLC manufacturer suggests a 4 GB microSD card, but it has been successful with up to a 32 GB. The card shall be formatted to 'FAT32' with default allocation size.

This functionality is enabled and running by default.

- If ever there is a blinking notification on the top-left of any screen saying, 'Data Not Logging', please contact CADARO.
- To remove the microSD card or start/stop data logging, follow the on-screen instructions.

The data logging scenarios and data logged is as follows:


Table 4: Data Logging Criteria

Log Trigger	Data Logged
Batch Reset	Batch Total Batch Number Batch Time Batch Average Flowrate/Min Tare Cal 1 Batch Time Cal 1 Batch Weight Cal 1 Factor Cal 1 Scale Weight Cal 1 Flowrate/Min Cal 1 Pre-Calibration Flowrate/min Cal 2 Batch Time Cal 2 Batch Weight Cal 2 Factor Cal 2 Scale Weight Cal 2 Flowrate/Min Cal 2 Pre-Calibration Flowrate/min
Active Batch	Batch Number Gross Tare Batch Mini-Number Tare Calibration Status Tare Calibration

Scale Save	Scale Weight Scale Batch
------------	-----------------------------

DIAGNOSTICS: PASSWORD PROTECTED FOR SUPERVISOR LEVEL ACCESS

Figure 50: Diagnostics Menu Screen




Data Monitoring

Figure 51: Data Monitor Hardwired Signals Screen




Amplifier Raw Reading is the value from the amplifier.

Figure 52: Data Monitor Hardwired Signals Screen



'Raw Readings' is the active status of all analog inputs and outputs and all digital inputs and outputs.

Figure 53: Data Monitor Two-Point Cal Screen



'Two-Point Cal' is used by CADARO to help troubleshoot any issues with 2-point Cal calculations.

Figure 54: Data Monitor Modbus Reads 1 Screen

MODBUS COMMUNICATIONS: READS 1							
6500	6502	6504	6506	6508	6510	6512	6514
0	0	0	0	0	0	0	0
6518	6520	6522	6524	6526	6528	6530	
0	0	0	0	0	0	0	
6534	6536	6538	6540				
0	0	0	0				
6542	6544	6546	6548				
0	0	0	0				

PREV	NEXT
BACK	

Figure 55: Data Monitor Modbus Reads 2 Screen

MODBUS COMMUNICATIONS: READS 2					
6550	6552	6554	6556	6558	6560
0	0	0	0	0	0
6568	6570	6572	6574	6576	6578
0	0	0	0	0	0
6586	6588	6590	6592	6594	6596
0	0	0	0	0	0
6604	6606	6608	6610	6612	6614
0	0	0	0	0	0
6620	6622	6624	6626	6628	
0	0	0	0	0	
6634	6636	6638	6640	6642	
0	0	0	0	0	
6648	6650	6652	6654	6656	
0	0	0	0	0	

PREV	NEXT
BACK	

Figure 56: Data Monitor Modbus Reads 3 Screen

MODBUS COMMUNICATIONS: READS 3				
6662	6664	6666	6668	6670
0	0	0	0	0
6850		6852		6854
0.000		0.000		0.000
6860		6862		6864
0.000		0.000		0.000
6870		6872		6874
0.000		0.000		0.000
6880		6882		6884
0.000		0.000		0.000

PREV

NEXT

BACK

Figure 57: Data Monitor Modbus Reads 4 Screen

MODBUS COMMUNICATIONS: READS 4			
6920	6925	6930	6935
Dynamic Text	Dynamic Text	Dynamic Text	Dynamic Text
6940	6945	6950	6955
Dynamic Text	Dynamic Text	Dynamic Text	Dynamic Text
6960	6965	6970	6975
Dynamic Text	Dynamic Text	Dynamic Text	Dynamic Text

PREV

NEXT

BACK

Figure 58: Data Monitor Modbus Writes 1 Screen

MODBUS COMMUNICATIONS: WRITES 1							
5000	5002	5004	5006	5008			
0	0	0	0	0			
5012	5014	5016	5018	5020	5022	5024	5026
0	0	0	0	0	0	0	0
5030	5032	5034	5036	5038	5040		
0	0	0	0	0	0		
5046	5048	5050	5052	5054	5056	PREV	NEXT
1	0	0	0	0	0		
5062	5064	5066	5068	5070	5072	BACK	
0	0	0	0	0	0		

Figure 59: Data Monitor Modbus Writes 2 Screen

MODBUS COMMUNICATIONS: WRITES 2							
5078	5080	5082	5084	5086	5088		
0	0	0	0	0	0		
5100	5102	5104	5106	5110	5112	5114	5116
0	0	0	0	0	0	0	0
5120	5122	5124	5126	5130	5132	5134	5136
0	0	0	0	0	0	0	0
5138	5140	5142	5144	5146	5148	PREV	NEXT
0	0	0	0	0	0		
5150	5152	5160	5162	5164	5166	BACK	
0	0	0	0	0	0		

Figure 60: Data Monitor Modbus Writes 3 Screen

MODBUS COMMUNICATIONS: WRITES 3							
5168	5170	5172	5174	5176	5178	5180	5182
0	0	0	0	0	0	0	0
5186	5188	5190	5192	5194	5196	5198	
0	0	0	0	0	0	0	

PREV	NEXT
BACK	

Figure 61: Data Monitor Modbus Writes 4 Screen

MODBUS COMMUNICATIONS: WRITES 4			
5200			
0			
5210	5212	5214	5216
0	0	0	0
5218	5220	5222	5224
0	0	0	0
5230	5232	5234	
0	0	0	
5236	5238	5240	
0	0	0	

PREV	NEXT
BACK	

Figure 62: Data Monitor Modbus Writes 5 Screen

MODBUS COMMUNICATIONS: WRITES 5			
5242	5244		
0	0		
5250	5252	5254	5256
0	0	0	0
5258	5260	5262	5264
0	0	0	0
5270	5272	5274	PREV NEXT
0	0	0	
5276	5278	5280	BACK
0	0	0	

Figure 63: Data Monitor Modbus Writes 6 Screen

MODBUS COMMUNICATIONS: WRITES 6	
5282	5284
0	0
5400	
Dynamic Text	
PREV	
BACK	

TARGET/PRESET TECHNICAL DATA SHEET

OBJECTIVE

PRO/ENTERPRISE:

This section will detail how to use the target control and preset functionality. The target is intended to be the batch weight. This target/preset can be changed by the operator by altering the available four presets and/or cycling through the presets until the active preset is the desired one.

Note: An output may be configured to control a sliding gate or some other mechanism if so desired. Contact CADARO for further information.

SCREEN CONTROL

Figure 64: Accessing Target Presets From Flow Sensor Menu



Figure 65: Accessing Target Presets From Flow Sensor Controls



Figure 66: Flow View Screen With Target Enabled




Figure 67: Enter Presets, Cycle Selected Preset, and Set Target Control Method



From the 'Flow Sensor View' screen, the operator can click on the 'Target Disabled' button or 'Flow Controls' to navigate to 'Target Settings' screen.

An additional screen focused on 'Target Control' can be navigated to from the 'Flow Sensor Menu' or 'Target Presets'. This screen allows for additional preset control and custom targets.

Figure 68: Target/Preset Control



Custom or Preset controls can be controlled from this ‘Target Control’ screen.

If required, a batch can be started/stopped from this screen to open/close a gate.

- The tare/empty weight represents the empty truck weight or starting point of a batch total weight.
- The target/full weight represents the desired amount for the batch.

When ‘Preset/Target Enable’ is enabled, the user can use this target in multiple ways.

- If a gate is installed on the chute, a %, weight, volume, or count target can be established to shut the gate.
- An alerting system could be set up to notify operators of action needed.
- Notify CADARO if there is a scenario to accommodate.

Figure 6: Enabling The Output



From the main ‘Initialization’ screen, the digital output must be enabled from the ‘Initialize IO’ screen of the ‘Setup Comms’ screen. Each channel has its own default digital output for control scenarios.

When Preset or Target is enabled, the specific channel should auto-enable the output, but it is worth double checking.

Figure 7: IO Enable Control and Status

SETUP DISCRETE INPUTS/OUTPUTS			
Air Activation Outputs Ch 1-4			
CH1 DO DISABLED	CH2 DO DISABLED	CH3 DO DISABLED	CH4 DO DISABLED
Gate Open/Close Outputs Ch 1-2			
CH1 DO OPEN DISABLED	CH1 DO CLOSE DISABLED	CH2 DO OPEN DISABLED	CH2 DO CLOSE DISABLED
Gate Open/Close Outputs Ch 3-4			
CH3 DO OPEN DISABLED	CH3 DO CLOSE DISABLED	CH4 DO OPEN DISABLED	CH4 DO CLOSE DISABLED
Active Flow Indicator Outputs Ch 1-4			
CH1 DO DISABLED	CH2 DO DISABLED	CH3 DO DISABLED	CH4 DO DISABLED
			PREV


WIRING INSTRUCTIONS

The PLC will have an IO card named '16DCOP' attached to it.

The wiring for a relay or air solenoid shall be as follows:

Figure 8: Output Wiring

EZRPL-IO-16DCOP



Contact CADARO for support.

VOLUME CONTROL TECHNICAL DATA SHEET


OBJECTIVE

PRO/ENTERPRISE:

This section will detail how to utilize volume control. Volume control is similar to target control; however the target is now a volumetric total rather than weight.

SCREEN CONTROL

Figure 9: Flow Sensor View. Volume Disabled View



From the 'Flow Sensor View' screen, the operator can click on the 'Volume Disabled' button or 'Flow Controls' to navigate to 'Volume Settings' screen.

Figure 10: Volume Control Setup Screen



When volume targeting is enabled, the totalizer will display the quantity of volumetric accumulation. If gate control is physically wired up, the gate will close when the volume target is reached.
 For example: 1000 bushels at 60 lb/bu is desired. Gate close command will activate when 1000 bushels is reached, equivalently 60,000 lbs.

Figure 11: Flow Sensor View. Volume Enabled View




Figure 12: Enabling The Output



From the main 'Initialization' screen, the digital output must be enabled from the 'Initialize IO' screen of the 'Setup Comms' screen. Each channel has its own default digital output for control scenarios.
 When Volume Control is enabled, the specific channel should auto-enable the output, but it is worth double checking.

Figure 13: IO Enable Control and Status

SETUP DISCRETE INPUTS/OUTPUTS			
Air Activation Outputs Ch 1-4			
CH1 DO DISABLED	CH2 DO DISABLED	CH3 DO DISABLED	CH4 DO DISABLED
Gate Open/Close Outputs Ch 1-2			
CH1 DO OPEN DISABLED	CH1 DO CLOSE DISABLED	CH2 DO OPEN DISABLED	CH2 DO CLOSE DISABLED
Gate Open/Close Outputs Ch 3-4			
CH3 DO OPEN DISABLED	CH3 DO CLOSE DISABLED	CH4 DO OPEN DISABLED	CH4 DO CLOSE DISABLED
Active Flow Indicator Outputs Ch 1-4			
CH1 DO DISABLED	CH2 DO DISABLED	CH3 DO DISABLED	CH4 DO DISABLED
			PREV


WIRING INSTRUCTIONS

The PLC will have an IO card named '16DCOP' attached to it.

The wiring for a relay or air solenoid shall be as follows:

Figure 14: Output Wiring

EZRPL-IO-16DCOP



Contact CADARO for support.

COUNT CONTROL TECHNICAL DATA SHEET


OBJECTIVE

PRO/ENTERPRISE:

This section will detail how to utilize count control. Count control is similar to target control; however the target is now a accumulated count total rather than weight.


SCREEN CONTROL

Figure 15: Flow Sensor View. Count Disabled View



From the 'Flow Sensor View' screen, the operator can click on the 'Count Disabled' button or 'Flow Controls' to navigate to 'Count Settings' screen.

Figure 16: Count Control Setup Screen



When count targeting is enabled, the totalizer will display the quantity of count accumulation. If gate control is physically wired up, the gate will close when the count target is reached.
 For example: 1,000,000 seeds at 200 seeds/lb is desired. Gate close command will activate when 1,000,000 seeds is reached, equivalently 5,000 lbs.

Figure 17: Flow Sensor View. Count Enabled View




Figure 18: Enabling The Output



From the main 'Initialization' screen, the digital output must be enabled from the 'Initialize IO' screen of the 'Setup Comms' screen. Each channel has its own default digital output for control scenarios.
 When Count Control is enabled, the specific channel should auto-enable the output, but it is worth double checking.

Figure 19: IO Enable Control and Status

SETUP DISCRETE INPUTS/OUTPUTS			
Air Activation Outputs Ch 1-4			
CH1 DO DISABLED	CH2 DO DISABLED	CH3 DO DISABLED	CH4 DO DISABLED
Gate Open/Close Outputs Ch 1-2			
CH1 DO OPEN DISABLED	CH1 DO CLOSE DISABLED	CH2 DO OPEN DISABLED	CH2 DO CLOSE DISABLED
Gate Open/Close Outputs Ch 3-4			
CH3 DO OPEN DISABLED	CH3 DO CLOSE DISABLED	CH4 DO OPEN DISABLED	CH4 DO CLOSE DISABLED
Active Flow Indicator Outputs Ch 1-4			
CH1 DO DISABLED	CH2 DO DISABLED	CH3 DO DISABLED	CH4 DO DISABLED
			PREV


WIRING INSTRUCTIONS

The PLC will have an IO card named '16DCOP' attached to it.

The wiring for a relay or air solenoid shall be as follows:

Figure 20: Output Wiring

EZRPL-IO-16DCOP



Contact CADARO for support.

AIR CONTROL TECHNICAL DATA SHEET

OBJECTIVE


PRO/ENTERPRISE:

This section will detail how to control the digital output for pneumatic solenoid. The air is intended to blow dust or material buildup under the Integral sensor's sensing box, around load cells.

Note: This output could be treated as an auxiliary output for custom usage, please consult with CADARO before using this output for non-air control.

SCREEN CONTROL

Figure 21: Flow Sensor View. Air Disabled View



From the 'Flow Sensor View' screen, the operator can click on the 'Air Disabled' button or 'Flow Controls' to navigate to 'Air Settings' screen.

Figure 22: Air Control Setup Screen



If in auto, air will blow after operator selects reset batch. It will blow for the 'Air On Time (Sec)' duration. When in manual, the air will blow on command when the operator selects 'Man Blow Air' for the same time duration.

Figure 23: Flow Sensor View. Air Enabled View






Figure 24: Enabling The Output



From the main 'Initialization' screen, the digital output must be enabled from the 'Initialize IO' screen of the 'Setup Comms' screen. Each channel has its own default digital output for control scenarios. When Air is enabled, the specific channel should auto-enable the output, but it is worth double checking.

Figure 25: IO Enable Control and Status




WIRING INSTRUCTIONS

The PLC will have an IO card named '16DCOP' attached to it.

The wiring for a relay or air solenoid shall be as follows:

Figure 26: Output Wiring

EZRPL-IO-16DCOP



Contact CADARO for support.

REMOTE RESET (HARDWIRED) TECHNICAL DATA SHEET


OBJECTIVE

PRO/ENTERPRISE:

This section will detail how to control the digital input for a binary pushbutton. The pushbutton is intended to allow for remote access to the PLC for use of resetting the batch.

Note: This input could be treated as an auxiliary input for custom usage, please consult with CADARO before using this input for non-reset control.

Figure 27: Screen Control



From the 'Main Menu' screen, the operator can click on the 'Utility Settings' button to navigate to 'Remote Reset Enable' button.

When enabled, the digital input from a remote pushbutton will in turn reset the batch when pressed.

Figure 28: Enabling The Input



From the main 'Initialization' screen, the digital input must be enabled from the 'Initialize IO' screen of the 'Setup Comms' screen. Each channel has its own default digital input for control scenarios.

When Remote Reset is enabled, the specific channel should auto-enable the input, but it is worth double checking.


Figure 29: IO Enable Control and Status



WIRING INSTRUCTIONS

The PLC will have an IO card named '16DCI' attached to it. The wiring for a remote reset pushbutton shall be as follows:

Figure 30: Input Wiring



Contact CADARO for support.


MARQUEE TECHNICAL DATA SHEET

OBJECTIVE

ENTERPRISE only:

This section will detail how to enable the Marquee data display device. The Marquee is intended to allow for remote display of active flow rate and batch total weight.

Figure 31: Screen Control



From the 'Main Menu' screen, the operator can click on the 'Utility Settings' button to navigate to 'Marquee Enable' button. When enabled, the data from the PLC will be displayed on the Marquee.


The data default display is 'Active Flow Rate' (lbs./min) and 'Batch Total' (lbs.).

WIRING INSTRUCTIONS

The PLC will have an RS422/485 port attached to it.

The wiring for a RS422 shall be as follows:

Figure 32: Input Wiring



Marquee Terminal Block	PLC Terminal Block
GND	GND
SD-	RD+
SD+	RD-
RD+	SD+
RD-	SD-

Contact CADARO for support.

HMI COMMS TECHNICAL DATA SHEET

OBJECTIVE

ENTERPRISE only:

This section will detail how to set up HMI comms to get remote access to the screen display and/or the data logging data. The IP setup is typically done over an IT controlled network but could be on a control/private network.

SCREEN CONTROL



Navigate to the 'Initialization' screen and then to 'Setup Comms/IO'.

'Setup HMI Comms' will open up a 'Built-in Ethernet Setup' Screen. From here the comms can be set up as follows.

1. The designated subnet needs to be known at this point.
 - Contact your IT if placing on IT network.
 - CADARO can support subnet if on control/private network.
2. Click 'Change IP Addr' and input the device IP address.
3. Subnet should be 255.255.255.0, unless otherwise specified by IT.
4. Gateway can be left blank unless otherwise by IT or CADARO.
5. Leave DNS and NTP as is found.
6. Select 'Save and Exit'.
7. Reboot the system by powering off the breaker, wait 5 seconds, power back on.

TESTING

From the remote desktop or other computer:

Ping the IP address assigned to the HMI during the setup. This is done by opening the 'Command Prompt' on a windows computer. Type 'ping xxx.xxx.xxx.xxx' where the x's refer to the device IP address.

```

c:\ Command Prompt
Microsoft Windows [Version 10.0.19045.3803]
(c) Microsoft Corporation. All rights reserved.
C:\Users\ >ping 192.168.1.10
    
```

- If good ping, comms are up and running.

- If no ping, see troubleshooting guide below.

USING REMOTE CAPABILITIES

The programs named 'EZ-RMC' and 'AVG Remote File Manager' may be used to monitor/control and access the data respectively.

1. EZ RMC version 1.2.30 and AVG Remote File Manager version 1.1.12 can be either purchased through the developer or through CADARO. A phone application can also be used for EZ RMC. Contact CADARO if interested in this method.
2. The EZ RMC allows for user specific monitor only or monitor and control capabilities.
3. The AVG Remote File Manager allows for remotely moving the data from the microSD card within the HMI. This data can then be parsed and analyzed on a desktop. The data from the microSD card can also be manually removed at any time without this program.

MODBUS TECHNICAL DATA SHEET

OBJECTIVE

ENTERPRISE only:

This section will detail how to view and control the Modbus data between a Master and Slave device. The Master will be whichever system is connected to the CADARO PLC, and the Slave will be the CADARO PLC.

This Modbus connection will address predetermined holding registers within the CADARO PLC database. With this functionality, the operator can view data and control functions remotely from the Master device.


Rockwell Automation-Logix Designer Setup and Program available upon request, contact CADARO at info@cadaro.com. Reference "CADARO-ROCKWELL ModBus Tech Sheet"

SCREEN CONTROL



Navigate to the 'Initialization' screen and then to 'Setup Comms/IO'. 'Modbus Enable' toggle button is used to allow Modbus Master to read from or write to the Slave PLC. Password is '3456'.

TESTING



With Supervisor credentials, the operator can navigate to 'Main Menu' -> 'Diagnostics' -> 'Data Monitoring'.

Modbus Read and Write register's statuses start on page three of the 'Data Monitoring'.

DATA READS

The data read tables for INTS, DINTS, FLOATS, and ASCII values are detailed below.

If there is any confusion or ambiguity around what a specific data read register represents, please reach out to CADARO for guidance.

DATA WRITES

The data write tables for INTS, DINTS, FLOATS, and ASCII values are detailed below.

Care should be taken when writing to the Slave PLC. The Slave PLC will accept the write at any point during the process and continue with the respective command/request for the write.

The control philosophy for Modbus control is intended to be regarded with the same understanding as would be used for local control at the CADARO HMI.

Note: Consider adding notes or logical restrictions to the Master device, when necessary, to avoid accidental writing to the Slave at inopportune times. Feel free to consult with CADARO if needed.

CADARO MODBUS REGISTER MAP

1. Table 5: Data Register Read Map – INTS

Register	Data Type	Description
6500	INT	CH1 Active Batch Number
6502	INT	CH1 Batch Time – sec
6504	INT	CH2 Active Batch Number
6506	INT	CH2 Batch Time – sec
6508	INT	CH3 Active Batch Number
6510	INT	CH3 Batch Time – sec
6512	INT	CH4 Active Batch Number
6514	INT	CH4 Batch Time – sec
6518	INT	Alarm – HMI Low Battery @ Value = 1
6520	INT	Alarm – PLC Low Battery @ Value = 1
6522	INT	Alarm – Sensor Fault @ Value = 1
6524	INT	Alarm – Sensor Max @ Value = 1
6526	INT	Alarm – Tare Tune Fault @ Value = 1
6528	INT	Alarm – Cal % Difference @ Value = 1
6530	INT	Alarm – Cal Factor Fault @ Value = 1
6534	INT	Sensor Channel 1 Selected
6536	INT	Sensor Channel 2 Selected
6538	INT	Sensor Channel 3 Selected
6540	INT	Sensor Channel 4 Selected
6542	INT	Cal Channel 1 Selected
6544	INT	Cal Channel 2 Selected
6546	INT	Cal Channel 3 Selected
6548	INT	Cal Channel 4 Selected

2. Table 2: Data Register Read Map – DINTS

Register	Data Type	Description
6550	DINT	CH1 Active Flowrate – lb/min
6552	DINT	CH1 Batch Average Flowrate – lb/min
6554	DINT	CH1 Batch Weight – lb
6556	DINT	CH1 Total Weight – lb
6558	DINT	CH1 Gross Weight – Raw Analog Signal
6560	DINT	CH1 Tare Weight – Raw Analog Signal
6568	DINT	CH2 Active Flowrate – lb/min
6570	DINT	CH2 Batch Average Flowrate – lb/min
6572	DINT	CH2 Batch Weight – lb
6574	DINT	CH2 Total Weight – lb
6576	DINT	CH2 Gross Weight – Raw Analog Signal
6578	DINT	CH2 Tare Weight – Raw Analog Signal
6586	DINT	CH3 Active Flowrate – lb/min
6588	DINT	CH3 Batch Average Flowrate – lb/min
6590	DINT	CH3 Batch Weight – lb
6592	DINT	CH3 Total Weight – lb
6594	DINT	CH3 Gross Weight – Raw Analog Signal

6596	DINT	CH3 Tare Weight – Raw Analog Signal
6604	DINT	CH4 Active Flowrate – lb/min
6606	DINT	CH4 Batch Average Flowrate – lb/min
6608	DINT	CH4 Batch Weight – lb
6610	DINT	CH4 Total Weight – lb
6612	DINT	CH4 Gross Weight – Raw Analog Signal
6614	DINT	CH4 Tare Weight – Raw Analog Signal
6620	DINT	Target/Preset Weight CH1
6622	DINT	Preset/Target Remaining CH1
6624	DINT	Preset/Target Tare/Empty Weight CH1
6626	DINT	Preset/Target Gross/Full Weight CH1
6628	DINT	Preset/Target Freefall CH1
6634	DINT	Target/Preset Weight CH2
6636	DINT	Preset/Target Remaining CH2
6638	DINT	Preset/Target Tare/Empty Weight CH2
6640	DINT	Preset/Target Gross/Full Weight CH2
6642	DINT	Preset/Target Freefall CH2
6648	DINT	Target/Preset Weight CH3
6650	DINT	Preset/Target Remaining CH3
6652	DINT	Preset/Target Tare/Empty Weight CH3
6654	DINT	Preset/Target Gross/Full Weight CH3
6656	DINT	Preset/Target Freefall CH3
6662	DINT	Target/Preset Weight CH4
6664	DINT	Preset/Target Remaining CH4
6666	DINT	Preset/Target Tare/Empty Weight CH4
6668	DINT	Preset/Target Gross/Full Weight CH4
6670	DINT	Preset/Target Freefall CH4

3. Table 3: Data Register Read Map – FLOATS

Register	Data Type	Description
6850	FLOAT	CH1 Active Cal Factor
6852	FLOAT	CH1 Cal 1 Cal Factor
6854	FLOAT	CH1 Cal 2 Cal Factor
6860	FLOAT	CH2 Active Cal Factor
6862	FLOAT	CH2 Cal 1 Cal Factor
6864	FLOAT	CH2 Cal 2 Cal Factor
6870	FLOAT	CH3 Active Cal Factor
6872	FLOAT	CH3 Cal 1 Cal Factor
6874	FLOAT	CH3 Cal 2 Cal Factor
6880	FLOAT	CH4 Active Cal Factor
6882	FLOAT	CH4 Cal 1 Cal Factor
6884	FLOAT	CH4 Cal 2 Cal Factor

4. Table 4: Data Register Read Map – ASCII

Register	Data Type	Description
6920	ASCII	File 1 Product/Description
6925	ASCII	File 2 Product/Description
6930	ASCII	File 3 Product/Description
6935	ASCII	File 4 Product/Description
6940	ASCII	File 5 Product/Description
6945	ASCII	File 6 Product/Description
6950	ASCII	File 7 Product/Description
6955	ASCII	File 8 Product/Description
6960	ASCII	File 9 Product/Description
6965	ASCII	File 10 Product/Description
6970	ASCII	File 11 Product/Description
6975	ASCII	File 12 Product/Description

5. Table 5: Data Register Write Map – INTS

Register	Data Type	Description
5000	INT	Manual Scale Batch Number
5002	INT	Manual Scale Save @ Value = 1
5004	INT	Manual Tare @ Value = 1
5006	INT	Reset Batch @ Value = 1
5008	INT	Reset Total @ Value = 1
5012	INT	Air Auto Toggle CH1: Auto @ Value = 1
5014	INT	Air Manual Cmd CH1: @ Value = 1
5016	INT	Air Auto Toggle CH2: Auto @ Value = 1
5018	INT	Air Manual Cmd CH2: @ Value = 1
5020	INT	Air Auto Toggle CH3: Auto @ Value = 1
5022	INT	Air Manual Cmd CH3: @ Value = 1
5024	INT	Air Auto Toggle CH4: Auto @ Value = 1
5026	INT	Air Manual Cmd CH4: @ Value = 1
5030	INT	Target Enable CH1: @ Value = 1
5032	INT	Target Preset Cycle Thru CH1: Next @ Value = 1
5034	INT	Target Start CH1: @ Value = 1, 0 = Stopped or Cancel
5036	INT	Target Custom/Preset CH1: Custom @ Value = 1
5038	INT	Gate Auto Toggle CH1: Auto @ Value = 1
5040	INT	Gate Manual Cmd CH1: @ Value = 1
5046	INT	Target Enable CH2: @ Value = 1
5048	INT	Target Preset Cycle Thru CH2: Next @ Value = 1
5050	INT	Target Start CH2: @ Value = 1, 0 = Stopped or Cancel
5052	INT	Target Custom/Preset CH2: Custom @ Value = 1
5054	INT	Gate Auto Toggle CH2: Auto @ Value = 1
5056	INT	Gate Manual Cmd CH2: @ Value = 1
5062	INT	Target Enable CH3: @ Value = 1
5064	INT	Target Preset Cycle Thru CH3: Next @ Value = 1
5066	INT	Target Start CH3: @ Value = 1, 0 = Stopped or Cancel
5068	INT	Target Custom/Preset CH3: Custom @ Value = 1
5070	INT	Gate Auto Toggle CH3: Auto @ Value = 1

5072	INT	Gate Manual Cmd CH3: @ Value = 1
5078	INT	Target Enable CH4: @ Value = 1
5080	INT	Target Preset Cycle Thru CH4: Next @ Value = 1
5082	INT	Target Start CH4: @ Value = 1, 0 = Stopped or Cancel
5084	INT	Target Custom/Preset CH4: Custom @ Value = 1
5086	INT	Gate Auto Toggle CH4: Auto @ Value = 1
5088	INT	Gate Manual Cmd CH4: @ Value = 1
5100	INT	Sensor Channel 1 Enable @ Value = 1
5102	INT	Sensor Channel 2 Enable @ Value = 1
5104	INT	Sensor Channel 3 Enable @ Value = 1
5106	INT	Sensor Channel 4 Enable @ Value = 1
5110	INT	Sensor Channel 1 Select @ Value = 1
5112	INT	Sensor Channel 2 Select @ Value = 1
5114	INT	Sensor Channel 3 Select @ Value = 1
5116	INT	Sensor Channel 4 Select @ Value = 1
5120	INT	Cal Channel 1 Select @ Value = 1
5122	INT	Cal Channel 2 Select @ Value = 1
5124	INT	Cal Channel 3 Select @ Value = 1
5126	INT	Cal Channel 4 Select @ Value = 1
5130	INT	Cal Save File 1 Select @ Value = 1
5132	INT	Cal Save File 2 Select @ Value = 1
5134	INT	Cal Save File 3 Select @ Value = 1
5136	INT	Cal Save File 4 Select @ Value = 1
5138	INT	Cal Save File 5 Select @ Value = 1
5140	INT	Cal Save File 6 Select @ Value = 1
5142	INT	Cal Save File 7 Select @ Value = 1
5144	INT	Cal Save File 8 Select @ Value = 1
5146	INT	Cal Save File 9 Select @ Value = 1
5148	INT	Cal Save File 10 Select @ Value = 1
5150	INT	Cal Save File 11 Select @ Value = 1
5152	INT	Cal Save File 12 Select @ Value = 1
5160	INT	Cal Load File 1 Select @ Value = 1
5162	INT	Cal Load File 2 Select @ Value = 1
5164	INT	Cal Load File 3 Select @ Value = 1
5166	INT	Cal Load File 4 Select @ Value = 1
5168	INT	Cal Load File 5 Select @ Value = 1
5170	INT	Cal Load File 6 Select @ Value = 1
5172	INT	Cal Load File 7 Select @ Value = 1
5174	INT	Cal Load File 8 Select @ Value = 1
5176	INT	Cal Load File 9 Select @ Value = 1
5178	INT	Cal Load File 10 Select @ Value = 1
5180	INT	Cal Load File 11 Select @ Value = 1
5182	INT	Cal Load File 12 Select @ Value = 1

5186	INT	Cal Load File @ Value = 1
5188	INT	Cal Save File @ Value = 1
5190	INT	Cal Reset @ Value = 1
5192	INT	Cal Perform 1 @ Value = 1
5194	INT	Cal Perform 2 @ Value = 1
5196	INT	Cal Force 1 @ Value = 1
5198	INT	Cal Force 2 @ Value = 1

6. Table 6: Data Register Write Map – DINTS

Register	Data Type	Description
5150	DINT	Manual Scale Entry
5210	DINT	Target % Freefall Setpoint CH1
5212	DINT	Target WT Freefall Setpoint CH1
5214	DINT	Target Preset 1 CH1
5216	DINT	Target Preset 2 CH1
5218	DINT	Target Preset 3 CH1
5220	DINT	Target Preset 4 CH1
5222	DINT	Target Custom Tare CH1
5224	DINT	Target Custom Target CH1
5230	DINT	Target % Freefall Setpoint CH2
5232	DINT	Target WT Freefall Setpoint CH2
5234	DINT	Target Preset 1 CH2
5236	DINT	Target Preset 2 CH2
5238	DINT	Target Preset 3 CH2
5240	DINT	Target Preset 4 CH2
5242	DINT	Target Custom Tare CH2
5244	DINT	Target Custom Target CH2
5250	DINT	Target % Freefall Setpoint CH3
5252	DINT	Target WT Freefall Setpoint CH3
5254	DINT	Target Preset 1 CH3
5256	DINT	Target Preset 2 CH3
5258	DINT	Target Preset 3 CH3
5260	DINT	Target Preset 4 CH3
5262	DINT	Target Custom Tare CH3
5264	DINT	Target Custom Target CH3
5270	DINT	Target % Freefall Setpoint CH4
5272	DINT	Target WT Freefall Setpoint CH4
5274	DINT	Target Preset 1 CH4
5276	DINT	Target Preset 2 CH4
5278	DINT	Target Preset 3 CH4
5280	DINT	Target Preset 4 CH4
5282	DINT	Target Custom Tare CH4
5284	DINT	Target Custom Target CH4

7. Table 7: Data Register Write Map – FLOATS

Register	Data Type	Description
----------	-----------	-------------

8. Table 8: Data Register Write Map – ASCII

Register	Data Type	Description
5400	ASCII	Cal Save Product Type

LOADING SOFTWARE FROM USB FILE

In special circumstances, CADARO may provide the customer with a USB drive. This drive will be preloaded with a file ready for download to the HMI.

Place the USB file into the 'Host' port on the HMI.

Figure 69: USB Port on HMI

USB Ports




- The HMI screen will automatically load a screen displaying all recognizable files.
- Ideally there will only be one file, select 'Accept' for it to be downloaded.
- Once the software update is completed, the system will automatically restart. If the system does not automatically restart, then power cycle the PLC control box.

Recording System Variables


TARE AND WEIGHT FACTOR

Tare can be found in many locations, but an easily navigable screen is 'Loadout Summary'. This can be found on the 'Flow Sensor Menu' screen. In the top-middle is the Tare.



Weight factor value can be thought of as a pre-calibration estimation. This value is customer and process specific. To find

and record this value, navigate from 'Main Menu' -> 'Utilities' -> 'Utility Settings' -> 'Weight Factors'. Each channel enabled may have different weight factors. These are important to record in the case data is wiped from the PLC database.




Locate the 'Tare' and 'WT-Factor' values.

Record: TARE: _____ WT_FACTOR: _____ Date: _____

CALIBRATION VALUES

Navigate to 'Save Cal Factors' screen within the 'Calibration Menu' screen.



Cal C1: _____ @ Pre-flow 1 _____ lbs/min @ Time 1 _____ seconds
 Cal C2: _____ @ Pre-flow 2 _____ lbs/min @ Time 2 _____ seconds

TROUBLE-SHOOTING TIPS

SLOW OPERATION OR DELAYED SCREEN TRANSITIONS

If the operator notices that the system is experiencing a delay when changing between screens or operating slower than normal, consider power cycling the system.

- Unplug the unit from the 110 volt AC power supply (AVOID opening the enclosure).
- Wait 30 seconds.
- Plug the power cord back into the 110 volt AC power supply and observe if performance improves.

INCORRECT GROSS READING

If the tare reading does not reflect the expected reading, consider checking the connections between the PLC control box and the flow sensor(s).

- If the gross reading shows zero "0" with a static weight (such as a bottle of water), check the connection between the PLC control box and the flow sensor(s).
- If the gross reading does not change when a static weight is placed on the sensor box/plate, and it has been verified that all shipping bolts (one top bolt and 2 bottom bolts) are removed, it is possible that a load cell is not functioning correctly. Contact your CADARO representative for further assistance.

UNRECOGNIZED FLOW RATE BY THE PLC

If the PLC is not recognizing the flow rate, consider the following:

- Ensure that the Integral flow sensor is properly connected.
- Check for any system restrictions that may be affecting the flow rate.
- If the issue persists, it could indicate a damaged load cell. Contact your CADARO representative for further assistance.

DATA SHARING ISSUES BETWEEN PLC AND SITE AUTOMATION SYSTEM VIA ETHERNET

To resolve issues related to data sharing between the PLC and a site automation system via Ethernet, follow these steps:

- Verify that the Ethernet connection is secure and properly connected.
- Check if the IP parameters at the location have changed and no longer match the CADARO PLC. You can use the IP configuration program from CADARO to investigate and adjust the settings accordingly. Although a newer version of the AVG IPConfig tool may exist, we recommended that ONLY version 1.0.2 (AVG IPConfig 1.0.2.exe) is installed/utilized to view and set IP addresses for external communication.

OPERATOR SCREEN ISSUES

If the screen on the PLC control box is not turning on, consider performing the following checks to ensure power is being provided to the unit:

- Verify that the unit is properly plugged into a 110 volt AC power source.
- If applicable, ensure the interruptible power supply has a visible green light (APC UPS units illustrate a green light under normal conditions). If the power supply is off despite proper connections, it may be faulty.
- If 110 volt AC power is being provided to the PLC control box, and the screen does not power up or respond to touch, there could be an issue with an internal component. Contact your CADARO representative for further assistance.

LOSS OF FACTORY SETTINGS DUE TO POWER LOSS

Values should remain so long as the PLC and HMI backup batteries are in working order.

If a power loss has resulted in the loss of factory settings.

- Replace both HMI and PLC batteries.
- Reference the original or latest calibration sheet. If unavailable, a new initialization and calibration needs to be completed.
- Manually input factory settings into the 'Manual Cal Factors' screen.

NO SIGNAL FROM FLOW SENSOR(S)

If there is no signal from the flow sensor(s), perform the following checks:

- Verify that the cable and connections are in good condition and securely connected on each end of the sensor cable.
- Contact your CADARO representative for further assistance.

NAN (NOT A NUMBER) VALUE

If you encounter a NAN value, which is seen when the code has been lost because of a power disruption (often associated with lightning strikes), please take the following steps:

- Record the C1 and C2 values along with their respective pre-cal flow rates.
- Power cycle the PLC by switching the breaker off for 30 seconds, then back on.
- Allow for bootup.
- Navigate to 'Save Cal Factors' screen within the 'Calibration Menu' screen.
- Check if the recorded values match the on-screen values.
 - If yes, the problem should be resolved.
 - If not, a manual 'Push Cal Factors' will need to be performed using the recorded values.
- Instructions for this can be found in 'Calibration Menu' section.

SERVICE AND REPAIR

CONTACT PHONE NUMBER AND EMAIL ADDRESS

For service or any questions regarding the product, please contact CADARO using the following details:

- Email: service@CADARO.com
- Phone: (806) 338-7478

WARRANTY

Warranty Voidance Notice: Please note that any alterations, repairs, or disassembly performed by unauthorized individuals or persons not authorized by CADARO are strictly prohibited and will result in the voidance of the warranty.

INTEGRAL SPECIFICATIONS

PRODUCT WEIGHTS

Figure 70: Product Weights

MODEL	Low Operating Range (lbs/min)*	High Operating Range (lbs/min)*	Inlet/Outlet Pipe Size (diameter round/square)*	Configuration	Flow Sensor Dimensions (L x W x H)	Flow Sensor Weight (lbs)
INTEGRAL NR/2K INTEGRAL NRL/2K	800	2,000	6" OD	Round	32 1/8" x 13" x 11 5/8"	67 -
INTEGRAL NS/5K INTEGRAL NSL/5K	1,750	5,000	9 3/4" x 9 3/4" ID	Square	30 3/8" x 16 1/4" x 15"	135 200
INTEGRAL NS/20K INTEGRAL NSL/20K	5,000	20,000	17 3/4" x 17 3/4" ID	Square	36 1/2" x 23 5/8" x 24 3/4"	210 275
INTEGRAL NS/50K INTEGRAL NSL/50K	17,500	50,000	29 3/4" x 29 3/4" ID	Square	36 1/2" x 37" x 35 5/8"	375 425

*Operating range can be calibrated to measure lower flow rates but overall range and accuracy requirements need to be considered.

RATED CAPACITY

The table below lists the acceptable flowrates (lbs/min) for 4 common models.

Table 6: Flow Sensor Specifications

Model	Measurement Range Lbs/Min	Measurement Range Kg/Minute ⁽¹⁾
Integral NR/2K	800-2,000	400-1,000
Integral NS/5K	1,750-5,000	800-2500
Integral NS/20K	5,000-20,000	2,300-9,100
Integral NS/50K	17,500-50,000	8,000-22,700

FLOW SENSOR DIMENSIONS

Figure 56: Integral NR/2K




Figure 57: Integral NS/5K and NSL/5K




Figure 58: Integral NS/20K and NSL/20K





Figure 59: Integral NS/50K and NSL/50K



INTEGRAL FLANGES

Figure 60: Integral NS/5K and NSL/5K Flange Detail




Figure 61: Integral NS/20K and NSL/20K Flange Detail





Figure 62: Integral NS/50K and NSL/50K Flange Detail



VERACITY SPECIFICATIONS

PRODUCT WEIGHTS

Figure 71: Product Weights

MODEL	Low Operating Range (lbs/min)*	High Operating Range (lbs/min)*	Inlet/Outlet Pipe Size	Configuration	Flow Sensor Dimensions (L x W)	Flow Sensor Weight (lbs)
VERACITY VR/600	200	600	4" ID	Round	18 ½" x 11"	25
			6" ID	Round	22" x 11"	28
VERACITY VR/2K	800	2,000	6" ID	Round	22 ¼" x 15"	50
VERACITY VR/4K	1,600	4,000	8" ID	Round	23" x 17"	60
			10" ID	Round	26" x 17"	65
VERACITY VR/5K	2,000	5,000	10" ID	Round	26" x 21"	75

RATED CAPACITY

The table below lists the acceptable flowrates (lbs./min) for 4 common models.

Table 7: Flow Sensor Specifications

Model	Measurement Range Lbs./Min	Measurement Range Kg/Minute ⁽¹⁾
Veracity NR/2K	800-2,000	400-1,000
Veracity NS/5K	1,750-5,000	800-2500
Veracity NS/20K	5,000-20,000	2,300-9,100
Veracity NS/50K	17,500-50,000	8,000-22,700

FLOW SENSOR DIMENSIONS

Veracity Models

Figure 72: Veracity VR600




Figure 73: Veracity VR2K






Figure 74: Veracity VR4K

VERACITY VR4K


Housing only: 13" high



TOP VIEW



ISOMETRIC VIEW



FRONT VIEW




CADARO Model	Notes	Catalog #	Description	Transition Ht.
Veracity VR/ 4K		50770	VR4K	
Veracity VR/ 4K Inlet	99603204-Inlet		VR4K Inlet: 8" to 8"	3"
Veracity VR/ 4K Inlet	99603207-Inlet		VR4K Inlet: 10-1/4" to 8"	6"
Veracity VR/ 4K Inlet	99603210-Inlet		VR4K Inlet: 7" to 7"	3"
Veracity VR/ 4K Outlet	99604205- Outlet		VR4K: 14-1/4" to 8"	6"
Veracity VR/ 4K Outlet	99604206- Outlet		VR4K: 14-1/4" to 10"	6"


Figure 75: Veracity VR5K

VERACITY VR5K


Housing only: 15" high



TOP VIEW



ISOMETRIC VIEW



FRONT VIEW




CADARO Model	Notes	Catalog #	Description	Transition Ht.
Veracity VR/ 5K		51481	VR5K	
Veracity VR/ 5K Inlet	99603209-Inlet		VR5K Inlet: 10" to 10"	3"
Veracity VR/ 5K Outlet	99604210- Outlet		VR5K: 18-1/4" to 10"	8"

VERACITY FLANGES

Figure 76: Veracity Flange Detail

Model	Catalog #	Stock #	Size	Adapter Description	Standard round angle flange size	Nordfab clamp size	A	B	C	D	
VR600- Inlet	50787	99603201	4" to 4"	WELDMENT,TRANS,INLET,4"TO4"	4"	6"	6.00	4.00	0.135	3.00	A= O.D.
VR600- Inlet	50785	99603203	6-1/4" to 4"	WELDMENT,TRANS,INLET,6-1/4"TO4"	6"	8"	8.50	6.25	0.135	6.29	B= I.D.
VR600- Outlet	50786	99604201	8-1/4" to 4"	WELDMENT,TRANS,OUTLET,8-1/4"TO4"	4"	6"	6.00	4.00	0.135	6.00	C= Thick
VR600- Outlet	50784	99604202	8-1/4" to 6"	WELDMENT,TRANS,OUTLET,8-1/4"TO6"	6"	8"	8.50	6.00	0.135	6.27	D= Depth
VR2K- Inlet	50783	99603202	6" to 6"	WELDMENT,TRANS,INLET,6"TO6"	6"	8"	8.50	6.00	0.135	3.00	All Inches
VR2K- Inlet		99603205	8-1/4" to 6"	WELDMENT,TRANS,8-1/4"TO6"	8"	10"	10.50	8.25	0.135	6.27	
VR2K- Outlet	50788	99604203	12-1/4" to 6"	WELDMENT,TRANS,OUTLET,12-1/4"TO6"	6"	8"	8.50	6.00	0.135	6.00	
VR2K- Outlet		99604204	12-1/4" to 8"	WELDMENT,TRANS,OUTLET,12-1/4"TO8"	8"	10"	10.50	8.00	0.135	6.00	
VR4K- Inlet		99603207	10-1/4" to 8"	WELDMENT,TRANS,INLET,10"TO8"	10"	12"	12.50	10.25	0.135	6.00	
VR4K- Inlet		99603204	8" to 8"	WELDMENT,TRANS,INLET,8"TO8"	8"	10"	10.50	8.00	0.135	3.00	
VR4K- Inlet		99603210	7" to 7"	WELDMENT,TRANS,INLET,7"TO7"	7"	9"	9.50	7.00	0.135	3.00	
VR4K- Outlet		99604205	14-1/4" to 8"	WELDMENT,TRANS,OUTLET,14-1/4"TO8"	8"	10"	10.50	8.00	0.135	6.00	
VR4K- Outlet		99604206	14-1/4" to 10"	WELDMENT,TRANS,OUTLET,14-1/4"TO10"	10"	12"	12.50	10.00	0.135	6.00	
VR5K- Inlet		99603209	10" to 10"	WELDMENT,TRANS,INLET,FM5000	10"	12"	12.50	10.00	0.135	3.00	
VR5K- Outlet		99604210	18-1/4" to 10"	WELDMENT,TRANS,OUTLET,18-1/4"TP10"	10"	12"	12.50	10.00	0.135	8.00	



PLC CONTROL BOX INFORMATION

SIGNAL OUTPUT VOLTAGE

Ethernet (standard) with Modbus option, and/or 4 channel analog outputs with 0-5 VDC, 0-10 VDC (optional)

PLC CONTROL BOX

12.8 lbs. for single channel

POWER RATING


1.3 amps at 110VAC


REQUIRED POWER AND SUGGESTED UPS

The PLC Control box requires a 110VAC and Un-interruptible Power Supply (UPS) [recommended] along with spike free, steady voltage. Electrical components may not be covered under OEM warrantee if a quality UPS is not used to power the system. It is further recommended that a professional licensed electrician (or other experienced/qualified individual) evaluate the quality of the original power supply to ensure that spike-free, steady is being supplied to the UPS and to the PLC Control box.

PLC CONTROL BOX DIMENSIONS

Figure 63. PLC control box Enclosure with 6-inch HMI






The power supply hole is in place for site installation to hard wire the PLC control box to the electrical supply. The site will need to drill the exact hole size to meet their conduit or other installation requirements.

PLC WIRING DIAGRAM

Figure 64: PLC Wiring Diagram



The PLC control box is designed to be plugged into a standard 120V AC outlet. (Reference the chapter and section titled Specifications, Required Power and Suggested UPS.) Should the customer decide to provide power without using the provided 3-prong outlet, reference the yellow highlighted wiring code in the above picture.

BATTERY REPLACEMENT GUIDE: HMI AND PLC BATTERIES

It is recommended that both batteries are replaced every 3 to 5 years, or when a battery alarm appears.


Reloading calibration profile after battery replacement:

- A partial RAM memory will be wiped when a battery replacement is performed on the HMI.
- **All RAM memory will be wiped** when a battery replacement is performed on the PLC.
- If either battery is replaced, or both, there needs to be some preparation beforehand to ensure smooth recovery to full function.


HMI Battery Pre-Replacement Preparation:

1. On the HMI, navigate to 'Flow Sensor Menu'.

Take a picture or write down the 'Flow Sensor Characteristics' values of 'Active Model Type' and 'Active Model Range'.



Navigate to the 'Load Cal Factors' screen. Take a picture or note down the values populated in each File.



2. After the battery/s have been replaced and the system reinitialized, input the saved calibration profile values to the respective calibration file.
3. To load the profile, select the file at the top of the column. The selected file will be white, while the others are gray.
4. Press 'Load Cal Factors' button at the top.
5. The unit will be back to functioning as before. If not, contact Cadaro Support.

HMI Battery Replacement Procedure:

1. Power down the unit by turning the breaker off.
2. Access HMI battery by opening the cover. There is a press-to-open latch opposite the pivot hinge.
3. The battery is near the pivot hinge.



4. Remove the battery and replace it with a new battery. Be sure to follow positive (+) and negative (-) installation instructions on or near where the battery is installed.




5. Power on the unit by turning the breaker on.
6. **Caution:** Do not touch any equipment or wires while power is applied.
7. Wait a maximum of 30 seconds for HMI panel to power up. If HMI does not power up, power down the system again by turning the breaker off. Wait 30 seconds. Power up the unit again by turning the breaker on.
8. If still no bootup from the HMI, try 6.a -6.c again.
9. If still no bootup, double check the battery installation is correct.
10. If still no bootup, contact Cadaro Support.

HMI Battery Specifications: LS14250 3.6 Volt 1200 mAh PLC Lithium 1/2AA Battery



PLC Battery Replacement Procedure

1. Power down the unit by turning the breaker off.
2. Access PLC battery by opening the cover. There is a press-to-open latch opposite the pivot hinge.
3. The battery is near the pivot hinge.



4. Remove the battery and replace it with a new battery. Be sure to follow positive (+) and negative (-) installation instructions on or near where the battery is installed.
*The PLC battery can be difficult to remove. It is suggested to use a small flathead screwdriver to pry up the pressure clip while using a second small flathead screwdriver to push the battery out.
5. Power on the unit by turning the breaker on.
6. **Caution:** Do not touch any equipment or wires while power is applied.
7. If the screen does not power up, refer to point 6 in the HMI battery replacement section.

PLC Battery Specifications: CR2032 3-Volt Battery



CADARO LIMITED WARRANTY

M&S Flowmatics Incorporated, doing business as CADARO, (“CADARO”) warrants that all CADARO equipment properly installed by CADARO, or its Distributor or Original Equipment Manufacturer (OEM) will operate according to the written product specifications. CADARO, its Distributor or OEM, at CADARO sole option may determine whether the product fails to meet its specification. Should a Distributor or OEM determine the product fails to meet its specification, it shall submit the claim to CADARO. CADARO must review the determination and accept the claim. All systems and components are warranted against defects in electronic equipment and defects in material/assembly for one (1) year beginning with the delivery date.

CADARO warrants the equipment against faulty workmanship and defective materials. If any equipment fails to conform to these warranties during the warranty period set forth above, CADARO will, at its option, repair or replace the non-conforming portion of the product returned within the warranty period subject to the following conditions:

- Upon discovery by Buyer of a nonconformity and provided such discovery is within the warranty period, Buyer will provide CADARO with prompt written notice within 30 days and provide a detailed explanation of the alleged deficiencies.
- Upon examination of the equipment CADARO will determine whether the equipment fails to meet its specifications consistent with the Operations Manual and such failure was not the result of accident, abuse, welding, misuse, neglect, alteration, improper installation, or improper testing by Buyer or any third party authorized by Buyer. Such determination of any alleged non-conformity shall be made in good faith; however, such determination shall be CADARO’ sole and exclusive determination.
- Only CADARO or a party authorized in writing is authorized to make any repairs. The equipment may not have been modified, altered, or changed by any person other than CADARO or a party CADARO authorizes to make the repair, or the warranty shall be void.
- CADARO will have a reasonable time to repair or replace defective equipment. The buyer is responsible for shipping charges to and from CADARO’s designated location.

THESE WARRANTIES EXCLUDE ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING WITHOUT LIMITATION WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. NEITHER CADARO NOR DISTRIBUTOR WILL, IN ANY EVENT, BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES.

CADARO AND BUYER AGREE THAT CADARO’ SOLE AND EXCLUSIVE LIABILITY HEREUNDER IS LIMITED TO REPAIR OR REPLACEMENT OF SUCH GOODS. IN ACCEPTING THIS WARRANTY, THE BUYER WAIVES ANY AND ALL OTHER CLAIMS TO WARRANTY.

SHOULD THE SELLER BE OTHER THAN CADARO, THE BUYER AGREES TO LOOK ONLY TO THE SELLER FOR WARRANTY CLAIM.

NO TERMS, CONDITIONS, UNDERSTANDING, OR AGREEMENTS PURPORTING TO MODIFY THE TERMS OF THIS WARRANTY SHALL HAVE ANY LEGAL EFFECT UNLESS MADE IN WRITING AND SIGNED BY A CORPORATE OFFICER OF CADARO AND THE BUYER.

“Patent”: www.cadaro.com

© 2024 M&S Flowmatics, Inc. Amarillo, TX USA. All Rights Reserved.

RECOMMENDED INFORMATION TO BE STORED IN PLC CONTROL BOX



Information

Date	
Serial Number Flow Sensor	
Serial Number PLC Control Box	
Load Cell Tare	
Wt. Factor	
Lined or Unlined Sensing Plate	
Auto Retare	
Dead Zone	
Software Version	
IP Address	
Subnet	
Gateway	
HMI IP Address	
Amplifier IP Address	

Calibration

	File 1	File 2	File 3	File 4	File 5	File 6	File 7	File 8	File 9	File 10	File 11	File 12
CAL1												
CAL2												
Pre-Cal Flow1												
Pre-Cal Flow2												
Time1												
Time2												
Scale1												
Scale2												
Tare (Tare @ Cal)												
Product												

service@cadaro.com

806-338-7478